


# TS-Clamp Quick Start Guide

The NexSens TS-Clamp thermistor string mooring clamps allow TS210 and T-Node FR nodes to be securely attached to a mooring line.




## TS-Clamp Installation

- 1 Unscrew the TS-Clamp to reveal the two distinctly sized, cut O-Rings.



- 2 Place the larger O-Ring onto the temperature string cable and the smaller O-Ring on the mooring line.
  - a. Offset the O-Rings so that when the temperature string is given slack, the O-Rings are aligned.



# TS-Clamp

## Quick Start Guide

- 3 Set the bottom half of the clamp below the O-Rings.
  - a. Ensure that the O-Rings are in the proper sized slots on the clamp.
- 4 Enclose the line and the string with the top half of the clamp.
  - a. Ensure to match the sizes of the O-Rings with the grooves in the clamp.
- 5 Tighten down the TS-Clamp and repeat these steps to place another TS-Clamp above the TS210 or T-Node FR.

