

CB-CCA CAGE ANTI-ROTATION COLLAR

INSTRUCTIONS

- 1 Place the cage security bracket onto the ends of the cage and buoy frame.




Figure 1: Place the cage and buoy frame within the security bracket mount.

- 2 Run the bolt with the pinhole downward through the buoy frame.
 - a. Place a lock washer and the castle nut onto the bolt.
 - b. Use a pair of 1-1/8" or adjustable wrenches to tighten the castle nut.
 - c. Ensure to align one of the troughs on the castle nut with the pinhole on the bolt.




Figure 2: Secure bracket connection with the buoy frame and cage.

- 3 Place the end plates over the center bolt.
 - a. Secure with the three remaining bolts, lock washers and nuts.




Figure 3: Use the end plates to cover the bracket mount openings for the cage and buoy frame.

- 4 Run the cotter pin through the hole in the center bolt.
 - a. Bend the long leg around one of the ridges on the castle nut.




Figure 4: Bend the long leg of the cotter pin.